



Quantum+™ Hardcoated
Polycarbonate VStream® Windscreen
for Suzuki® GSX-S1000GX



VStream®

VStream® Windscreen Patent No. 7,387,328

N20247 Low Dark Tint

N20248 Mid Light Tint

N20249 Clear Tint

Thank you for purchasing a National Cycle product. Read these instructions carefully and thoroughly before beginning work. Dealers, if installing this windshield for a customer, please give them this manual upon completion. It contains information needed to properly maintain and use this product.

Description:	VStream® Replacement Windscreen	Model:	2024-Current Suzuki® GSX-S1000GX
Part Number:	N20247/N20248/N20249	Installation Time:	15 min. Difficulty Level: Easy

PACKAGE CONTENTS

ITEM	PART NO.	DESCRIPTION	QTY.
A		VStream Windscreen Polycarbonate, Quantum+ Hardcoated	1

TOOLS REQUIRED

5.0mm Hex Wrench or Allen Key



All OEM hardware will be reused.



ATTENTION: Special notes and cautionary measures which can prevent damage to the accessory or vehicle.



NOTE: Tips for facilitation of operation, control and adjustment, as well as maintenance work.



Step 1

PREPARATION Place motorcycle securely on its centerstand.

OEM WINDSCREEN REMOVAL

Step 1

First, Use a 5mm Hex Wrench or Allen Key, loosen the four screws securing the windscreen to the motorcycle and remove the OE Windshield from the bike.

Next, remove the OE grommets from the OE windshield.



Take note the orientation of the grommets before removal. Small diameter shoulder on grommet should face toward windscreen mount, large diameter towards washer/screw head.



All OEM hardware will be reused.

VSTREAM INSTALLATION

Step 2

Install the OE grommets into the VStream Windscreen in the same orientation the grommets were installed in the OE windscreen.

Use a 5mm Hex Wrench or Allen Key, install your new VStream Windscreen (A) to the OEM mount points using the original mounting screws and washers. Tighten screws until snug.



Do not over-tighten screws. Over-tightening may damage wellnuts and windscreen. Tighten only until snug.



Step 2



Step 3

The installation is now complete.

Double-check your work for fit and tightness before riding.

Ride safe and enjoy your new VStream Windscreen!

Step 3

CLEANING AND MAINTENANCE

To clean the screen, wash with a clean soft cloth and plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths. Paint, glue residue or grease removal: Moisten cotton wad with naphtha or turpentine followed by a wash as above.

National Cycle Shield Wash™ (N1401-01) makes a good daily cleaner and comes with a handy travel-size bottle. Shield Wash is safe for all windshields and helmet visors

Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with household glass cleaners. Do not allow brake fluid, alcohol, or strong solvents to contact the screen.

RAIN REPELLENT

Do not use rain protective products made for glass. We recommend National Cycle's RainZip® (N1410-01) to keep your windscreen clear in rainy weather.



Register Your Windshield Online at www.nationalcycle.com

National Cycle 3-Year Limited Warranty

National Cycle hereby warrants to the original registered owner of a National Cycle polycarbonate windshield for a period of three years from the date of purchase against breakage. This limited warranty is expressly limited to the replacement of the polycarbonate windscreen. This limited warranty does not include scratches, coating failure, cosmetic wear and tear, replacement of hardware, or any consequential damages or expenses including labor cost of installation, removal and/or replacement, inconvenience, inbound freight expenses or damage to any other component of the motorcycle or any other accessories. Certain chemicals, generally known as acidic hydrocarbons, are known to cause polycarbonate damage and will not be covered under this limited warranty. Please refer to the cleaning instructions supplied with all National Cycle windshields.

Visit www.nationalcycle.com for further details, or call or e-mail National Cycle.

WARNING

Never ride your motorcycle with loose accessory mounting hardware. Check the hardware for tightness regularly.

Today's motorcycles are built to withstand the moderate loads imposed on them by the foreseeable addition of an accessory(ies). If an accessory(ies) adversely affects your motorcycle's stability, immediately remove the accessory(ies). Do not ride a motorcycle that exhibits unsafe handling traits. Have experienced service personnel correct any problem before riding with the accessory(ies) installed. For further questions concerning handling problems associated with an accessory(ies), contact your dealer, motorcycle manufacturer, or accessory manufacturer.

Sunlight reflected off the inside curvature of the windscreen can, at certain times of day, cause extreme heat buildup on the motorcycles instruments and possibly even melt them. Exercise care in parking to avoid this. Park your motorcycle facing the sun or place an opaque object over this area.