

Description:	Quantum® Hardcoated Polycarbonate UTV Windshield, Rear	Type of Vehicle:	Kymco UXV700
Part Number:	N30604	Installation Time:	15 min.

Please read these instructions carefully and thoroughly before beginning work. Dealers, if installing this windshield for a customer, please give them this manual. It contains information needed to properly maintain and use this product.



Attention:
Special notes and cautionary measures which can prevent damage to the accessory or vehicle.




Note:
Tips for facilitation of operation, control and adjustment, as well as maintenance work.

Parts List	Tools Required
------------	----------------

Item	Part No.	Description	Qty.	Tools and Notes
1		Rear Windscreen	1	With Grommets Installed

Parts Bag#1276

2	44-449371-000	Clamp, Wraparound, 1.50	4	Clamp for Top Rail
3	44-449370-000	Clamp, Wraparound, 1.75	4	Clamp for Side Rail
4	44-449380-000	Retaining Pin	8	
5	49-490355-000	Washer, Flat, Black	8	
6	55-563131-000	Screw, Phillips, #12 x 1.25,	8	Phillips Screw Driver



TOOLS
#2 Phillips Head Screw Driver


PREPARATION
This Kit has been carefully packed and inspected at the factory. Carefully unpack the windshield, sort the parts, and make sure you have everything required to complete the installation to the vehicle.

INSTALLATION


Align Clamps, Figure 1

1. Snap the Wraparound 1.5" Clamps (2) on the rear frame of the vehicle as shown. Repeat on right side. **Figure 1**

2. Snap the Wraparound 1.75" Clamps (3) on the rear frame of the vehicle as shown. Repeat on right side. **Figure 1**

 Note the orientation of the male half (with embossed part number). **Figure 1**

3. Lift bed of vehicle.

 Place fasteners within reach of assembling clamps.

4. With a second person's help, place windshield on rear frame. **Figure 2**

Install Fasteners, Illustration A, Figure 2

5. Loosely install Windshield at sides using:


Retainer Pin (4)


Black Washer (5)

(#5 place between Shield Grommet and Clamp)

Screw (6)

(Phillips Screw Driver)

 Note the Hex shape of Retainer Pin, and male Clamp half.

 Note the access holes for optional Cab Roof, item a.




Figure 1



Figure 2




Illustration A




Figure 3



Figure 4

Check Alignment

6. Check the alignment and position of the windshield and make sure it is even and symmetrical. Check clearance by lowering bed of vehicle. **Figure 3**

Final Tightening

7. Securely tighten the Machine Screws in the Wrap-around Clamps. **(Phillips Screw Driver)**

8. Install optional roof. **Figure 4 (5.5mm Hex Key)**

CLEANING AND MAINTENANCE

To clean the screen, wash with a clean soft cloth, plenty of warm water and if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft cham- ois make good cleaning cloths. **Paint, glue residue or grease removal:** Moisten cotton with naphtha or tur- pentine followed by a wash as above.

Do not clean polycarbonate in hot sun or high temper- atures. Do not clean the screen with glass cleaners.

Do not allow brake fluid, alcohol, or strong solvents to contact the screen.

RAIN REPELLENT

Do not use rain protective products made for glass. We recommend National Cycle's **RainZip®** (N1410-01) to help shed water in rainy weather.

⚠ WARNING

CAUTION: The maximum speed for trailering the vehicle with the windshield is 65 MPH minus headwind speed. Always face windshield forward (in direction of travel) while carrying on truck or trailer.

CAUTION: Plasticizers from some new vehicle covers or other coverings that are made from PVC may damage your windshield. Do not use a new cover for a few days. Remove it from its package and leave in the sun or other warm location. Use caution when storing your vehicle covered with your windshield installed, to avoid gases from becoming trapped under the cover.

Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with glass cleaners. Certain chemicals, generally known as acidic hydrocarbons, are known to cause polycarbonate damage. Do not allow brake fluid, alcohol, or strong solvents to contact the screen.

RAIN REPELLENT

Do not use rain protective products made for glass. We recommend National Cycle's **RainZip®** (N1410-01) to help shed water in rainy weather.